



**AX1371**  
Sabot GP PHD  
KTM 450SXF

- 1 PM02-07-005
- 2 NE01-11-001 Screws 6x25mm
- 2 NE01-04-002
- 1 NE04-01-107



PM02-07-005 + NE01-04-002



NE01-06-026 + NE10-01-004



**AX1371**  
Sabot GP PHD  
KTM 450SXF

- 1 PM02-07-005
- 2 NE01-11-001 Screws 6x25mm
- 2 NE01-04-002
- 1 NE04-01-107



PM02-07-005 + NE01-04-002



NE01-06-026 + NE10-01-004

