



**AX1377**

Sabot GP PHD  
HVA FC/FX250-350

- 1 PM02-07-001
- 2 NE01-11-001 Screw 6x25mm
- 2 NE01-04-002
- 2 NE01-09-001
- 1 NE04-01-110



PM02-07-001 + NE01-04-002

NE01-09-001

NE01-11-001



**AX1377**

Sabot GP PHD  
HVA FC/FX250-350

- 1 PM02-07-001
- 2 NE01-11-001 Screw 6x25mm
- 2 NE01-04-002
- 2 NE01-09-001
- 1 NE04-01-110



PM02-07-001 + NE01-04-002

NE01-09-001

NE01-11-001