

FITTING INSTRUCTIONS FOR R&G GENERIC ALI TOE GUARD TG0002A2 (silver), TG0002B2 (black)



- Locate the Toe Guard on the underside of the rear swingarm, on the nearside of the bike, in front of the rear sprocket.
- Mark and drill two 5mm holes into the underside of the swingarm.
- Tap the holes to M6
- Insert M6x20mm long allen screws through block and tighten block to the swingarm.

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RACING RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorised (if not pre-authorised the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in resellable condition, in the opinion of R&G Racing. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P - at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G Racing

Unit 5K, Blacknest Industrial Park, Blacknest Road, Alton, Hampshire, GU34 4PX Tel: +44 (0)870 220 6380 Fax: +44 (0)1420 521101 www.rg-racing.com Email: info@rg-racing.com



Notice de montage

TG0002A2 / B2 PROTECTION DE COURONNE / CHAINE



Conseil de montage:

1-Localiser en dessous du bras oscillant l'endroit où vous désirez placer la protection de chaine/couronne.

Attention cette opération doit être réalisée avec prudence.

Veillez à bien positionner la protection, celle-ci ne doit pas être en contact ni avec la chaine, ni avec la couronne.

2- Une fois l'emplacement défini, vous devrez marquer les enplacements des vis (vis fournies dans le kit), puis perçer le dessous du bras oscillant à l'aide d'un forêt diam 5mm en utilisant le gabarit de perçage joint).

3- Tarauder les deux trous à l'aide d'un taraud M6

4- Insérer les vis M6 x20 dans les trous de fixation de la protection, placer l'ensemble sur le bras oscillant, puis bloquer fermement les deux vis allen sur le bras oscillant