


# SHAD

## SYM SYMPHONY 125 '15

### KIT TOP SOSM15ST



1 261845 x1



2 260821 x4  
Ø14 Ø9 x 22



3 303017 x2  
Ø6



4 304176 x2  
M6 x 50 DIN 912



5 304093 x2  
M6 x 40 DIN 7991



6 302021 x4  
M6

### ! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

