


# SHAD

## BENELLI TRK 502 '17 KIT TOP B0TR57ST



1 262095 x1



2 260213 x4  
Ø16 Ø9 x 12



3 303017 x6  
Ø6



4 302021 x4  
M6



5 304079 x2  
M6 x 30  
Din 7380



6 304029 x2  
M6 x 35  
Din 7991



7 261026 x2  
Ø14 Ø9 x 4



8 260927 x8  
Ø14 Ø9 x 15



9 262196 x1



10 262197 x1



11 304201 x2  
M6 x 40  
Din 7380



12 304071 x2  
M6 x 50  
Din 912

### ! WARNING!

GB

Do not fully tighten the screws until it is ensured that the KIT is correctly attached and aligned.

E

No apretar los tornillos del todo hasta asegurarse que el KIT está correctamente colocado y alineado.

D

Ziehen Sie die Schrauben nicht ganz fest, bevor Sie sich nicht vergewissert haben, daß der Bausatz korrekt eingestellt und ausgerichtet ist.

I

Non stringere del tutto le viti fin tanto non si è sicuri che il kit è collocato correttamente e allineato.

F

Ne pas serrer les vis avant d'être sûr que le KIT est correctement monté et ajusté.

