


## MONTEER 5000S USER MANUAL


### ACCESSORY/STRUCTURE




MONTEER 5000S




Handlebar mount



Battery pack



Micro USB Cable



Aero bar compatible strap




Nylon strap




3mm Hex

### HOW TO INSTALL



### HOW TO INSTALL BATTERY PACK



### BATTERY INDICATOR

When the light is off, press the power button to display the remaining power.




FLASH RED  
0%-5%





RED  
6%-20%



GREEN  
21%-100%




### HOW TO RECHARGE






### SWITCHING THE LIGHTING MODE

Click power button to turn on, hold 1.5s to turn off  
When you turn the light on, it lights up in the last lighting mode you used.  
(Mode memory function)




## LUMENS/RUN TIME

MODE	BRIGHTNESS	ECO	LOW	MID	HIGH	FLASH
	LUMENS	100	500	1000	2000	0-1150
	h:min	90:00	45:00	17:00	07:00	35:30
	LUMENS	350	800	1600	3200	0-1600
	h:min	30:00	13:00	06:00	03:00	13:30
	LUMENS	500	1250	2500	5000	0-2500
	h:min	28:00	09:30	04:30	02:00	09:30

## OPTIONAL PARTS



Helmet mount



TTA front mount

\*Adaptable accessories (sold separately)

## WARNING



## EN WARRANTY

The Magicshine lighting system is warranted for 24 months from the date of purchase.

If you register the lighting system on the Magicshine website you will receive a bonus 6 month warranty.

Battery packs and AC adapters have a 6 month warranty, however, there is no bonus warranty available.

The warranty is limited to defects in material and workmanship on the lighting system itself, the battery pack and the AC adapter.

The warranty is only valid if the affected parts have not been tampered with and there is no intentional damage. Please keep your proof of purchase in a safe place. Proof of purchase must be presented in the event of any claim. Please contact the specialist retailer from whom you purchased the device for complaint or warranty claim.

Alternatively, you can send your complaint or claim directly to Magicshine at

Tel: (+86) 755-295 536 69

Fax: (+86)755-275 897 77

E-mail: [support@magicshine.com](mailto:support@magicshine.com) (order from Magicshine.com online store)

[service@magicshine.com](mailto:service@magicshine.com) (order from other sales channels)

In the event of a justified warranty claim and delivery of a replacement device, you will only be entitled to a model available when replacing. The manufacturer retains the right to make technical modifications.

## ANSI FL 1 STANDARD

