



INSTRUCTION

Page 1/3

C-RACER
www.c-racer.com



Model	Product	Code
YAMAHA Tenere 700/T7	CHAIN GUARD in SILVER & BLACK color	NP-YT7-S & NP-YT7-b

CONTENTS

1. 1pcs metal base
2. 2pcs screws M5X10 (allen-oval-washers)
3. 1pcs screw M5X20 (allen-oval-washer)
4. 1pcs adapter $\Phi 12\Phi 8\Phi 8\text{mm}$

The product is for race use only

For any further information please do not hesitate to contact us:
Tel.: +30 2108075387 Email: info@c-racer.com




These are the parts you will find inside the package
Read the instructions before starting the installation.



Unscrew the 2 screws holding the guard on the front and inside the scissor.




Then remove the screw that is visible from the outside, as shown on the photograph.



Remove the metal base that the protector has on the front part.



Screw it onto the new guard, but do not tighten the screws.



Slide the protector into place and screw it on back screw without tightening it. Be sure to place the adapter on the inside of the protector as shown in the photo.



Screw the screws back at its old position with the same screws and tighten them.



Finally tighten the screws from the top of the base and the external.



This will be your final result. Enjoy your rides!