

Antivols cable à code

FR

MODE D'EMPLOI

- Ouvrir le cadenas avec le code par défaut 0000.
- Tourner la molette dans le sens horaire jusqu'au clic.
- Régler votre code personnel.
- Tourner la molette dans le sens antihoraire.
- Votre cadenas est prêt.
- Attacher votre vélo à un point fixe si nécessaire en l'associant au câble.
- Lubrifier régulièrement la serrure et les extrémités de l'anse.

ATTENTION !

- En cas de perte de vos clés, gardez toujours chez vous une clé ou le code pour la copie.

GARANTIE :

- 2 ans, couvre les défauts matériels ou de fabrication, de fonctionnement, hors défaut esthétique ou négligence, contre preuve d'achat et retour du produit défectueux. Valable partout dans le monde.

EN

HOW TO USE

- Open the lock with 0000.
- Rotate the knob clockwise.
- Set your new combination.
- Rotate the knob counterclockwise.
- Your lock is ready.
- Secure your bicycle to a fixed post by using the cable.
- Regularly oil both cylinder and shackle ends.

WARNING !

As a safeguard against losing the keys, always keep the copy code or a spare key at home.

GARANTEE :

- 2 years covers product failure due to material defects or workmanship, except cosmetic damages or misuse, against proof of purchase and return of defective product. Applies worldwide.