





CP0449

FITTING INSTRUCTIONS FOR CP0449 CRASH PROTECTORS
HONDA CB125R 2018-

Page | 1



PICTURE A




PICTURE B

THIS KIT CONTAINS THE ITEMS PICTURED AND LABELLED BELOW.
DO NOT PROCEED UNTIL YOU ARE SURE ALL PARTS ARE PRESENT.

Please note that the way the kit is packed does not necessarily represent the way of mounting to the bike

THE PARTS SHOWN MAY BE REPRESENTATIVE ONLY (FOR CLARITY OF INSTRUCTIONS ONLY)

LEFT SIDE



RIGHT SIDE



CP0449

LEGEND

ITEM 1= CRASH PROTECTOR (B0431 WITH CS341) (x2).

ITEM 2= CRASH PROTECTOR CAPS (BC0002) (x2).

ITEM 3= SPACER (S1132) (x2)

ITEM 4= M10x1.25x110mm LONG HEX HEAD BOLT (x2).

ITEM 5= LOCK-WASHERS (LW0001) (x2).

Page | 2



ITEM 6= M10 PLAIN WASHERS (x2).

ITEM 7= MARKING TOOL (T0007) (x1)

Please note that in cases where kits are packed with rubber washers holding the components onto the bolt – *the rubber washers should be thrown away!*

TOOLS REQUIRED

- Socket set to include 14 and 19mm sockets and wrench.
 - Allen key set
- Torque wrench (up to 40Nm).
 - 28mm Hole Saw



R&G

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



CP0449



PICTURE 3



PICTURE 4



PICTURE 5



PICTURE 6



PICTURE 7



PICTURE 8



CP0449

INSTRUCTIONS

Page | 4

- Remove the right-hand side of the belly pan by removing the two bolts shown in pictures 1 and 2, and the bolt that secures the two sides of the belly pan together, found underneath the bike.
- Remove the right-hand engine mount bolt. Shown in picture 3.
- Screw the marking tool into the engine mount, shown in picture 4.
- Re-fit the right-hand belly pan and unscrew the marking tool until it contacts the pan.
- Carefully push/tap the belly pan into the marking tool to mark the position of the hole.
- With the hole position marked remove the right-hand side of belly pan. Drill a pilot hole through the marking.
- At this point we recommend re-fitting the belly pan again, to ensure that the pilot hole is in the correct position in relation to the marking tool. See picture 6.
- Open the hole to 28mm, using the 28mm hole saw (picture 7). Using a file, the hole may need to be opened to allow the crash protector to fit through.
- Re-fit the belly pan, to ensure the hole lines up with the engine mount.
- Repeat this process for the left side of the bike.
- Once both holes have been drilled, permanently re-fit the belly pan.
- Take the right side 110mm M10 bolt (item 4) and slide a plain washer (item 6) up to the head of the bolt, followed by a lock-washer (item 5). Pass the bolt through a crash protector (item 1) and then slide the spacer (item 3) over the bolt and up to the protector.
- Fit this assembly to the right side engine bolt hole, through the belly pan. See Picture B.
- Repeat this process for the left side of the bike.
- **PLEASE NOTE BOBBIN MUST BE POSITIONED AS IN PICTURE 'C' ABOVE WITH BIGGER END TOWARD FRONT OF BIKE.** Tighten bolt until you feel some compression from inside the protector. Turn a little more so that you feel the compression increase slightly. Then apply a quarter turn. Tighten to 40Nm of torque (do not exceed this figure, as damage can occur to the motorcycle and the bolt).
- When the protectors are tight fit the caps in to the protector.
- If not already fitted fit bubble sticker into recess of bobbin cap.

DUE TO THE RISK OF CROSS-THREADING OF BOLTS ETC; WE ALWAYS RECOMMEND THAT OUR PRODUCTS BE FITTED BY ONE OF OUR OFFICIAL DEALERS OR A QUALIFIED MECHANIC.

Issue 1 06/08/2018 (LF)

Issue 2 13/08/18 (LF)

Digital copies of these instructions are available to download from www.rg-racing.com

R&G

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ

Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



CP0449

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in resellable condition, in the opinion of R&G. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



CP0449

NOTICE DE MONTAGE CP0449 PROTECTIONS CRASH
HONDA CB125R 2018-

Page | 6




PHOTO A





PHOTO B

Le kit contient les articles exposés ci-dessous, vérifier que toutes les pièces soient présentes avant de procéder au montage.

La façon dont le kit est emballé ne correspond pas forcément à la façon de monter les pièces sur la moto.

LES PARTIES PRESENTEES PEUVENT ETRE UNIQUEMENT REPRESENTATIVES (POUR LA CLARTE DES INSTRUCTIONS UNIQUEMENT)

CÔTÉ GAUCHE



R&G

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



CP0449
CÔTÉ DROIT

LÉGENDE

- ARTICLE 1= PROTECTION CRASH (B0431 AVEC CS341) (x2).
ARTICLE 2= BOUCHONS DE PROTECTION CRASH (BC0002) (x2).
ARTICLE 3= ENTRETOISE (S1132) (x2)
ARTICLE 4= M10x1.25x110mm BOULON (x2).
ARTICLE 5= RONDELLES DE BLOCAGE (LW0001) (x2).
ARTICLE 6= M10 RONDELLES (x2).
ARTICLE 7= OUTIL DE MARQUAGE (T0007) (x1)

Page | 7

Notez que si les kits sont emballés avec des rondelles en caoutchouc servant à tenir les composants, *ces rondelles doivent être jetées !*

OUTILS REQUIS

- Clé à cliquet + douilles de 14 et 19mm.
 - Clé Allen
- Clé dynamométrique (à 40 Nm).
 - 28mm Scie trou

ARRIÈRE MOTO



AVANT MOTO

PHOTO C




PHOTO 1




PHOTO 2



CP0449



PHOTO 3



PHOTO 4



PHOTO 5



PHOTO 6





PHOTO 7

PHOTO 8

CP0449

NOTICE DE MONTAGE

Page | 9

- Enlever le ventre de carénage du côté droit en enlevant les 2 boulons indiqués sur les photos 1 et 2, et le boulon qui fixe les 2 côtés du ventre de carénage ensemble, sous la moto.
- Enlever le boulon de support moteur, voir photo 3.
- Visser l'outil de marquage dans le support moteur, voir photo 4.
- Remonter le ventre de carénage du côté droit puis dévisser l'outil de marquage jusqu'à ce qu'il touche le ventre.
- Tapoter le ventre de carénage sur l'outil de marquage pour marquer la position du trou.
- Un fois la position du trou marquée, enlever le ventre de carénage du côté droit. Percer un trou pilote dans le marquage.
- A ce stade, nous recommandons de remonter le ventre de carénage, pour vous assurer que le trou pilote soit correctement localisé par rapport à l'outil de marquage. Voir photo 6.
- Ouvrir le trou à 28mm, à l'aide d'une scie trou de 28mm (photo 7). Le trou peut être ajusté à l'aide d'une lime pour permettre à la protection crash de se positionner correctement.
- Remonter le ventre de carénage, pour veiller à ce que le trou s'aligne avec le support moteur.
- Répéter ce process du côté gauche de la moto.
- Une fois que les 2 trous ont été percés, remonter le ventre de carénage de façon définitive.
- Prendre le boulon 110mm du côté droit (article 4) puis glisser une rondelle (article 6) sur la tête du boulon, suivie d'une rondelle de blocage (article 5). Passer le boulon dans la protection crash (article 1) puis glisser l'entretoise (article 3) sur le boulon et sur la protection.
- Monter l'ensemble sur dans le trou de boulon moteur du côté droit et à travers le ventre de carénage. Voir Photo B.
- Répéter ce process du côté gauche de la moto.
- **LA PROTECTION DOIT ETRE POSITIONNEE COMME EN "C" AVEC LE CÔTÉ ARRONDI LE PLUS GROS EN DIRECTION DE L'AVANT DE LA MOTO.** Tourner un peu plus afin d'accentuer légèrement la compression. Faire un quart de tour. Serrer à 40Nm de couple (Ne pas excéder cette valeur, car cela pourrait endommager la moto et le boulon).
- Insérer les stickers en caoutchouc dans le creux des 2 capuchons de protections crash.
- Insérer les capuchons dans les 2 protections.

DU FAIT DES RISQUES POTENTIELS ENGENDRES PAR L'INSTALLATION DE NOS PROTECTIONS, NOUS RECOMMANDONS TOUJOURS QUE LE MONTAGE SOIT EFFECTUE PAR UN DE NOS REVENEURS OFFICIELS OU UN MECANICIEN QUALIFIE.

Issue 1 06/08/2018 (LF)

Notice disponible au téléchargement sur www.rg-racing.com

R&G

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



CP0449

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



CP0449

MONTAGEANLEITUNG FÜR CP0449 STURZPADS
HONDA CB125R 2018-

Page | 11




ABBILDUNG A





ABBILDUNG B

ALLE KIT-TEILE SIND UNTEN ABGEBILDET UND GEKENNZEICHNET. BEVOR SIE MIT DER MONTAGE BEGINNEN, ÜBERPRÜFEN SIE, DASS ALLE TEILE VORHANDEN SIND.

Hinweis: Die Verpackung der Teile stellt nicht die Reihenfolge der Montage dar.

DIE UNTEN ABGEBILDETEN TEILE DIENEN LEDIGLICH ZUR ERKLÄRUNG

LINKE SEITE



RECHTE SEITE



CP0449

LIEFERUMFANG

- ARTIKEL 1= STURZPAD (B0431 MIT CS341) (x2)
- ARTIKEL 2= STURZPAD-SCHUTZKAPPEN (BC0002) (x2)
- ARTIKEL 3= DISTANZHALTER (S1132) (x2)
- ARTIKEL 4= M10x1;25x110mm SECHSKANTSCHRAUBE (x2)
- ARTIKEL 5= ZAHNSCHEIBE (LW0001) (x2)
- ARTIKEL 6= M10 UNTERLEGSCHLEIBE (x2)
- ARTIKEL 7= REISSNADEL (T0007) (x1)

Page | 12

Hinweis für Kits mit Plastikunterlegscheiben an den Schrauben – *Diese Plastikunterlegscheiben werden nicht für den Einbau benötigt!*

SIE BENÖTIGEN FOLGENDES WERKZEUG

- Steckschlüsselsatz inkl. 14 & 19mm Steckschlüssel
 - Satz Inbusschlüssel
- Drehmomentschlüssel (bis 40Nm)
 - S28mm Lochsäge




ABBILDUNG 1




ABBILDUNG 2

R&G

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



CP0449



ABBILDUNG 3



ABBILDUNG 4



ABBILDUNG 5



ABBILDUNG 6



ABBILDUNG 7



ABBILDUNG 8



CP0449

MONTAGEANLEITUNG

Page | 14

- Entfernen Sie die rechte Seite der unteren Abdeckung, indem Sie die zwei Schrauben entfernen, die in den Abbildungen 1 und 2 abgebildet sind, sowie die Schraube, die beide Seiten der unteren Abdeckung befestigt (unter dem Motorrad).
- Entfernen Sie die rechte Motorschraube – siehe Abbildung 3.
- Die Reißnadel in die Motorhalterung eindrehen – siehe Abbildung 4.
- Die untere Abdeckung für die rechte Seite wieder anbauen und die Reißnadel aufdrehen, bis sie die Abdeckung berührt.
- Vorsichtig die Abdeckung eindrücken, bis die Reißnadel eine Markierung an der Innenseite hinterlässt, um somit die Position der Öffnung zu markieren.
- Danach die rechte Seite der unteren Abdeckung entfernen und ein Loch an der markierten Stelle vorbohren.
- Es empfiehlt sich nun, die untere Abdeckung wieder zu montieren, um zu überprüfen, dass die Vorbohrung an der richtigen Position mit der Reißnadel ist – siehe Abbildung 6.
- Mit einer 28mm Lochsäge ein 28mm Loch in der Verkleidung vorbohren (Abbildung 7). Das Loch muss eventuell mit einer Schleiffeile weiter geöffnet werden, um das Sturzpad durchschieben zu können.
- Montieren Sie die untere Abdeckung wieder, um zu sichern, dass die Öffnung mit dem Motorhalterung bündig ist.
- Diesen Vorgang an der linken Seite des Motorrads wiederholen.
- Wenn beide Löcher gebohrt sind, die untere Abdeckung endgültig wieder montieren.
- Nehmen Sie die M10 Schraube für die rechte Seite (Artikel 4) und eine Unterlegscheibe (Artikel 6). Schieben Sie die Unterlegscheibe bis zum Schraubenkopf hoch. Eine Zahnscheibe (Artikel 5) nehmen und zur gerade montierten Unterlegscheibe hochschieben. Die Schraube mit den Unterlegscheiben in eins der Sturz pads (Artikel 1) einführen. Danach den Distanzhalter (Artikel 3) über die Schraube zum Sturzpad hochschieben.
- Diese Einheit an der Öffnung für die rechte Motorschraube durch die untere Abdeckung – siehe Abbildung B.
- Diesen Vorgang an der linken Seite des Motorrads wiederholen.
- **BITTE DARAUf ACHTEN, DASS DAS STURZPAD WIE IN ABBILDUNG ‘C’ POSITIONIERT IST – DAS GRÖßERE ENDE DES STURZPADS ZUM VORDERTEIL DES MOTORRADS GERICHTET.** Die Schraube festziehen, bis Sie etwas Druck vom Inneren des Sturz pads spüren. Noch etwas drehen, bis Sie merken, dass der Druck sich leicht erhöht, dann noch eine Vierteldrehung anwenden. Mit 40 Nm Anzugsmoment anziehen. (Nicht überdrehen – dies kann zu einer Beschädigung des Motorrads und der Schraube führen. 40 Nm Anzugsmoment nicht überschreiten!)
- Wenn die Sturz pads ordnungsgemäß befestigt sind, die Schutzkappen an beiden Sturz pads anbringen.
- Wenn noch nicht bereits montiert, montieren Sie die Bubble-Aufkleber in den Vertiefungen der Sturzpad-Schutzkappen.

UM EIN EVENTUELLES ÜBERDREHEN ODER VERKANTEN DER SCHRAUBEN ZU VERMEIDEN, EMPFEHLEN WIR IMMER, UNSERE KITS VON EINEM UNSERER OFFIZIELLEN HÄNDLER ODER EINEM QUALIFIZIERTEN ZWEIRADMECHANIKER MONTIEREN ZU LASSEN.

Ausgabe 1 06/08/2018 (LF)
Ausgabe 2 13/08/18 (LF)

R&G

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com



CP0449

Eine digitale Version dieser Montageanleitung kann auf folgender Seite heruntergeladen werden: www.rg-racing.com

Page | 15

CONSUMER NOTICE

The catalogue description and any exhibition of samples are only broad indications of the Products and R&G may make design changes which do not diminish their performance or visual appeal and supplying them in such state shall conform to the order. The Buyer acknowledges no representation or warranty (other than as to title) has been given or will apply to the Products other than those in R&G's order or confirmation and the Buyer confirms it has chosen the Products as being of merchantable quality and suitable for its particular purposes. Where R&G fits the Products or undertakes other services it shall exercise reasonable skill and care and rectify any fault free of charge unless the workmanship has been disturbed. The Buyer is responsible for ensuring that the warranty on the motorcycle is not affected by the fitting of the Products. On return of any defective Products R&G shall at its option either supply a replacement or refund the purchase money but shall not be liable if the Products have been modified or used or maintained otherwise than in accordance with R&G's or manufacturer's instructions and good engineering practice or if the defect arises from accident or neglect. Other than identified above and subject to R&G not limiting its liability for causing death and personal injury, it shall not be liable for indirect or consequential loss and otherwise its liability shall be limited to the amounts paid by the Buyer for the Products or the fitting or service concerned. These terms do not affect the Buyer's statutory rights.

R&G RETURNS POLICY (NON-FAULTY GOODS)

Returns must be pre-authorized (if not pre-authorized the return will be rejected). Goods may only be returned direct to us if they were purchased direct from us (customer must prove if necessary). Otherwise to be returned to original vendor. Goods must be in re-sellable condition, in the opinion of R&G. All returns are subject to a 25% restocking and handling fee (25% of the gross value exc. P&P – at the prevailing price at time of purchase). The customer must pay any and all carriage charges. No returns of discontinued products, unless within 14 days of purchase. This policy does not affect your statutory rights and does not refer to faulty goods.

R&G

Unit 1, Shelley's Lane, East Worldham, Alton, Hampshire, GU34 3AQ
Tel: +44 (0)1420 89007 Fax: +44 (0)1420 87301 www.rg-racing.com Email: info@rg-racing.com